
# MODE OF USE

To embed the wick with fuel, make up and down movements.



- 2 Light the wick.
- Once the wick is lit: Tilt the torch forward gradually until the fuel drips on the burning wick and generates a flame that will fall on the ground to be burnt.



IMPORTANT:
The appropriate
operating position is with
the aerator positioned
upwards

## SUGGESTIONS

To keep the flame in self-combustion, adjust the proportions of the fuel mixture.

## DISASSEMBLY

Repeat steps 4 - 3 - 2 - 1 in reverse order.

# **MAINTENANCE**

Do not leave fuel residues in - Always check all parts of t

- Replace the wick if necess
- In case of loss or damage purchase original spare part







**Operating manual** 

Drip Torch 5 liters



- Warnings Page 1
- Operating instructions and mixture preparation Page 2
- Mode of use, suggestions, disassembly and maintenance.



### WWW.INFOREST.COM.AR

ventas@inforest.com.ar comex@inforest.com.ar

inforest\_incendiosforestalesinforest.cba

Brasil 1238 Alta Gracia Córdoba - Argentina CP: 5186 Tel/Fax: +54(0)3547430529

# Thank you for purchasing an INFOREST Drip Torch.

Please read the following instructions carefully before using the product in order to have a satisfactory experience.

# $oldsymbol{\Lambda}$

# **ATTENTION**

- Before using it, inspect all parts of the product to ensure its functions properly.
- Check inside the container and verify that the vent tube is in place.
- Check the o-ring of the cap.
- Check the condition of the spout-wick assembly.

#### **IMPORTANT**

- Ignition equipment should only be used by trained and experienced personnel. All precautions must be taken to avoid danger to you and others.
- You should always identify and plan an escape route before starting the burn, since the rapid spread of fire can be dangerous to you or others, including extinguishing equipment that may be at a considerable distance from you.
- The product uses petroleum-based fuels that must be handled with caution.

## **OPERATING INSTRUCTIONS**

#### **CARRYING POSITION**



1 ASSEMBLY FOR OPERATING USE

Unscrew the brass nut and place it to one side.



Take the cap/spout/wick assembly of the container and remove it.



Release the fuel passage by unscrewing the plug.



Then, screw the plug into the housing parallel to the passage to prevent the loss of the part.

Check that the ball, nut and filter are in place inside the cap.

#### MIXTURE PREPARATION

Take the container and prepare the mixture according to suggested proportions.



6 ATTENTION!
Check the o-ring of the filling mouth.



Take the cap /spout/wick assembly and place it on the mouth of the container.

- Align the assembly so that the loop is opposite to the aerator.
- Take the nut and tighten it to be able to use the product.



Aeration: Unscrew the aeration screw counterclockwise (at least two full turns).

